

CrossWave® Cordless Multi-Surface Wet Dry Vac LED display lights | Support

LED Light	Situation/Cause	Resolution/Behavior
3 Solid White Lights	Battery fully charged	Full charge takes up to 4 hours
1 - 2 Solid White Lights	Battery 10 - 69% charged	For more runtime charge machine
White Flashing Lights	Battery is charging	Depending on the amount of charge, could be 1, 2 or 3 lights flashing
1 Red Flashing Light	Less than 10% battery	Charge machine
3 Solid Red Lights	Brush roll obstruction	See Brush not turning steps
2 - 3 Red Flashing Lights	Error reading	Turn off machine pushing Hard Floor button twice Wait 10 minutes Restart machine by pressing Hard Floor button If not resolved Contact Us