

# PowerFresh LIFT-OFF 1544 Series

## No Steam

### Possible issues:

[What has the tank been filled with](#)

[Ready light](#)

[Steam from liftoff pod](#)

[Steam from foot](#)

- Verify there is water in the tank.
- What has been the tank been filled with?
  - Ask what has been used to fill the tank?
  - Tank should preferably be filled with distilled, R.O., or BISSELL Scented Demineralized water. They can also use just tap water.
    - If tap water has been used, inform them that minerals from tap water can build up more easily than using distilled or reverse osmosis (R.O.) water as they don't form build up over time.
- Is the Ready Light on?

If:	Then:
Yes	Wait for READY light to stop blinking (1 to 2 min). Then push ON/OFF button making it light up, and push HI so it lights up.


	
No	Try a different outlet. Still no light go to No Power Troubleshooting

[<back to top>](#)

- Remove Lift-Off Pod and attach tool connector or hose



Is there steam from the Lift-Off pod?

If:	Then:
No	<p>Unplug unit, wait 10 seconds and remove tool connector and clean hole where spray head inserts with a paperclip.</p>  <p>Now reattach the tool connector, plug in, turn on, and test for steam.</p>

If still no steam and unit is within warranty

**External Support: Contact BISSELL**

- If steam resumes, turn off & unplug, then remove tool connector and reattach the Lift-Off pod to the base pushing it evenly straight into the machine until it clicks.
- NOTE: There only be a small gap between the machine and the pod. (A gap the thickness of a credit card, as anything larger means the pod is not in place).



Yes

Reattach the pod, plug back in and test for steam to the floor.

- If still no steam, continue troubleshooting.

If steam resumes Clean hole where spray head inserts.  
Reattach the Foot until it clicks into place.


**External Support: Contact BISSELL**

[<back to top>](#)

- Remove the foot of the unit. Is there steam with the foot removed?

**If:**

**Then:**

No	<p>Turn off, Unplug the unit and wait 10 seconds. With a paperclip, clean the steam opening on the bottom of the unit.</p>  <p>After removing the paperclip, lay the unit on the ground pointed away from any people, pets, or furniture. Now, plug in, turn on, and select a steam setting to test for steam without the foot.</p> <ul style="list-style-type: none"> <li>▪ If it starts to steam, turn steam off and wait 10 seconds to attach the foot. Then place on the ground and select a steam setting. If it doesn't steam with the foot attached,</li> </ul> <div data-bbox="511 1276 1403 1438" style="border: 1px solid black; padding: 5px;"> <p><b>External Support:</b> Contact BISSELL.</p> <ul style="list-style-type: none"> <li>▪ If it does steam, problem is resolved.</li> </ul> </div>
Yes	<p>Reattach the foot and test for steam. If there is none,</p> <div data-bbox="511 1522 1403 1675" style="border: 1px solid black; padding: 5px;"> <p><b>External Support:</b> Contact BISSELL / replace part/product</p> </div>